


# Reverse Neo Process

IRVINE SENSORS CORPORATION

## Substrate Preparation



- 1a) Prep 30 mil aluminum shim stock
- 1b) Apply polyimide & cure

**PROPRIETARY INFORMATION** Not to be duplicated, used, or disclosed in whole or part for any purpose other than evaluation. This restriction does not limit the right to use information contained herein if it is obtained from another source without restriction.


Copyright © 2000 Irvine Sensors Corporation  
Unpublished work - all rights reserved.

#3

# Reverse Neo Process

IRVINE SENSORS CORPORATION

## Substrate Preparation



- 1a) Prep 30 mil aluminum shim stock
- 1b) Apply polyimide & cure

**PROPRIETARY INFORMATION** Not to be duplicated, used, or disclosed in whole or part for any purpose other than evaluation. This restriction does not limit the right to use information contained herein if it is obtained from another source without restriction.